

## How to use 'Reset' button on NVR Solo?

### Purpose

The 'Reset' button on NVR Solo can be use to...

1. Reset admin account password
2. Restore NVR to factory default

### Reset admin account password procedures

1. Verify that the system is fully booted
2. Insert your reset tool into the reset button on the back of the device
3. Press and hold the reset button for **8 seconds**, release until the buzzer **beeps one time** and the system status LED flashes in blue.

- NS-1040/ NS-1080:



- NS-8060/ NS-8065:



4. System will restart and the administrator's password is now reset to 'admin'.

### Restore NVR to factory default procedures

1. Press and hold the reset button for **14 seconds**, release until the buzzer **beeps twice** and the system status LED flashes in orange.
2. System will restart and all settings are reset to default.